


ABUIER

HAND BLENDER

USER MANUAL



Model: HB-2028L

CUSTOMER SERVICE

Our customer service team is standing by to assist you if you have any questions or concerns.



www.abuler.com




support@abuler.com



1-833-654-5626

DESCRIPTION:

- A. Inching switch
- B. Switch I
- C. Switch II
- D. Motor unit
- E. Button
- F. Blender stick
- G. Chopping bowl lid
- H. "S" blade
- I. Chopping bowl
- J. Whisk holder
- K. Whisk
- L. Milk frother beater
- M. Vessel



CAUTION

Please read the instructions carefully and completely before using the appliance.

1. Before plugging into a socket, check whether the voltage corresponds to the rating label of the appliance.
2. Always disconnect the blender from the power supply if it is left unattended and before assembling, disassembling, and cleaning.
3. Don't plug the appliance into the power supply until it is fully assembled and always unplug before disassembling the appliance or handling the blade.
4. Don't let children play with this appliance.
5. Don't let the motor unit, cord, or plug get wet.
6. Never use a damaged appliance. If it has been damaged, please get it to approved service center to be checked or repaired.
7. If the supply cord is damaged, it must be replaced by approved service center.

8. Don't let any excess cord hang over the edge of the table or worktop or touch any hot surface.

9. The blades are very sharp!

10. Don't place the appliance in hot ingredients.

11. The appliance is constructed to process normal household quantities.

12. Neither the measuring beaker, nor the chopping bowl is micro-wave proof.

13. Use the appliance for no longer than 1 minute continuously, and don't operate on hard food for longer than 15 seconds.

14. This appliance should not be used by children and care should be taken when used near children.

15. Switch off the appliance and disconnect from supply before changing accessories or approaching parts which move when in use.

16. Clean the hand blender with a dry cloth.


17. The user should follow instructions stated in this manual for details on how to clean surfaces in contact with food, the operating times and speed for accessories.

18. Do not misuse the hand blender. Care should be taken when handling the sharp cutting blades, emptying the bowl and during cleaning.

19. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capacities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

20. Children should be supervised to ensure that they do not play with the appliance

HOW TO USE THE HAND BLENDER




The hand blender is perfectly suited for preparing dips, sauces, soups, mayonnaise and baby food as well as for mixing and milkshakes.

1. Insert the blender stick onto the motor unit until it locks.
2. Put the hand blender in the mixing container. Then press switch I or switch II .
3. Unplug the appliance, then press the eject button to remove the blender stick after use.

You can use the hand blender in the measuring beaker and other vessels.

Caution: The blade is very sharp!

HOW TO USE YOUR CHOPPER



- The chopper is perfectly suited for hard food, such as chopping meat, cheese, onion, herbs, garlic, carrots, walnuts, almonds, prunes etc.
- **Don't chop extremely hard food, such as ice cubes, nutmeg, coffee beans and grains.**

Before chopping...

1. Carefully remove the plastic cover from the blade.

Caution: The blade is very sharp! Always hold it by the upper plastic part.

2. Place the blade on the center pin of the chopper bowl. Press down the blade and lock the bowl in place. Always place the chopper bowl on the anti-slip base.

3. Place food in the chopper bowl.

4. Place the chopping bowl lid on the chopper bowl.

5. Place the motor unit on the chopper bowl lid until it locks.

6. Press the switch to operate the chopper. During processing, hold the motor unit with one hand and the chopper bowl the other.


7. After use, unplug the appliance, then press the eject button to remove the motor unit.

8. Remove the chopping bowl lid.

9. Carefully take out the blade.

10. Remove the processed food from the chopper bowl.


HOW TO USE YOUR WHISK



Use the whisk for whipping cream, beating egg whites and mixing sponges and ready-mix desserts.

1. Insert the whisk into the whisk holder, and then slot the gear box onto the motor unit until it locks.
2. Place the whisk in a vessel. Then press switch I or switch II to operate it.
3. Unplug the appliance, then press the eject button to remove the gear box after use. Then pull the whisk out of the gear box.

HOW TO USE YOUR MILK FROTHER



The milk frother is intended for frothing milk quickly and perfectly.

1. Insert the milk frother beater into the whisk holder unit firmly.
2. Connect the coupling unit to the motor unit.
3. Press the switch to activate the blender , and press the turbo button after approximately 1 minute to prevent ingredients splashing.
4. Unplug the appliance, then press the eject button to remove the gear box after use. Then pull the milk frother beater out of the gear box.

CLEANING

Cleaning the motor unit and chopping bowl lid only with a damp cloth only. **Do not immerse the motor unit in water!**

- 1.All other parts can be cleaned in the dish washer. However, after processing very salty food, you should rinse the blades right away.
- 2.Also, be careful not to use an overdose of cleaner or decalcifier in your dishwasher.
- 3.When processing food with color, the plastic parts of the appliance may become stained. Wipe these parts with vegetable oil before placing them in the dishwasher.
- 4.The blades are very sharp, please pay attention to them when cleaning.
- 5.Unplug the appliance before cleaning.

PROCESSING GUIDE (FOR 500ML CHOPPING BOWL)

Food		Maximum	Operation time
meat		250g	15sec
herbs		50g	10sec
nut, almonds		150g	15sec
cheese		100g	10sec
bread		80g	10sec
onions		200g	10sec
biscuits		150g	10sec
soft fruit		200	10sec
Yeast dough	flour	250g	10sec
	water	165g	
	cream	2.5g	
	power	2.0g	
	sugar	1.2g	

ABUIER



www.abuler.com



support@abuler.com



1-833-654-5626



Made in China