

RR-1520T movable reflector panel

Assembly instructions

● Parts list

1. 2 x Tube A with wheels (Ø31.5 x 50cm)
2. 1 x Tube B with aluminum head (Ø31.5 x 78cm)
3. 1 x Tube C (Ø31.5 x 72cm)
4. 2 x Tube D with tilting bracket CLD-15 (Ø31.5 x 100cm)
5. 2 x Tube E with spigot and aluminum head (Ø19 x 109cm)
6. 2 x Tube F (Ø19 x 91cm)
7. 2 x Tube G with vertical interface and aluminum head (Ø19 x 76.5cm)
8. 2 x Tube H with vertical interface (Ø19 x 73cm)
9. 1 x White diffuser

● Installation

Pic.1. Assemble 1 tube B with 1 tube C. (The small picture is the partially enlarged picture. Tighten the hex screw after putting the tubes to the right position.)

Pic.2 Assemble the finished part in Pic.1 with 2 Tube A.

Pic.3 Install 2 Tube D with the finished part in Pic.2.

Pic.4 Connect Tube E with Tube F respectively

Pic.5 Assemble the two poles in Pic.4 with the rack in Pic.3.

Pic.6 Connect Tube G with Tube H respectively

Pic.7 Assemble the two poles in Pic.6 with the part in Pic.5

Pic.8 Put up the white diffuser with the rubber band on the four corners and make sure the Velcro is stuck firmly. (As shown in the enlarged picture.)

