MOMAN






Thank you for choosing MOMAN product. Please read this manual carefully before use and follow all instructions mentioned herein.

Caring For Your MOMAN Product (

- . Please keep the product in a dry, clean, dust-free environment.
- . Keep corrosive chemicals, liquids and heat source away from the product to prevent mechanics damage.
- Use only a soft and dry cloth for cleaning the product.
- Malfunction may be caused by dropping, impact of external force.
- . Do not attempt to disassemble the product. Doing so voids warranty.
- Please have the product checked or repaired by authorized technicians if any malfunctions happened.
- . Failure to follow all the instructions may result in mechanics damage.
- · Warranty does not apply to human errors.

Package List



[Not included with CP1(A)]














Product Introduction



Windshield

- 6 Phone Connector (Type-C or Lightning)
- 2 Transmitter Indicator 3 Type-C Charging Port
- Receiver Indicator 8 Type-C or Lightning Port

- 4 Clip
- Switch Key

Indicator- TX Transmitter

Function/Status	Light
Power on	•
Power off	••
Pairing	(0)
Paired	•
Mute	•
Unmute	•
Low battery alarm	•••
Charging	•

Indicator- RX Receiver

Function/Status	Light
Power on	•
Power off	0
Pairing	• • •
Paired	•

Operations

TX

Power On/Off

On: Press the Switch Key once.

Off: Long press the Switch Key for 3s.

Pairing

After power on, plug the receiver into device and the system will pair automatically.

* If there are more than one set of transmitter and receiver co-working, the pairing may be confused or break off. You could long press the Switch Key for 8s to rematch.

Mute

After pairing, press the Switch Key once to mute. Press it again to cancel mute.

4. Charging

5V/1A:

Please fully charge the TX transmitter with charging cable before use.

RX

1. Power On/Off

On: Plug in the device

Off: Plug out of the device

Connecting

Connect the receiver to phone.

- * Use the Type-C to USB Adapter to connect with computer.
- * OPPO/VIVO/IQOO/Realme mobile phones can be used normally only when OTG function (please search "OTG" on the settings) turns on.

3. Pairing

After power on, plug the receiver into device and the system will pair automatically.

4. Charging

There is no battery in RX receiver and no need to recharge during live. If the phone is low power during live, it can be recharged directly through the Type-C/Lightning port on the RX receiver.

* Some phone models do not support this function.



Specifications

TX Transmitter

Transmission Frequency	2.4GHz
Transmission Distance	≥10m
Latency	≤20ms
Sensitivity	-38dB±3dB
Frequency Response	20Hz-20KHz
Sampling Rate	48KHz
SNR	≥75dB
Working Time	6H
Working Temperature	-10°C-50°C
Dimensions	15x57x15mm
Weight	7g

RX Receiver

Transmission Frequency	2.4GHz
Frequency Response	20Hz-20KHz
Dimensions	44x26x8mm
Weight	4g

Moman (UK) Limited

- Unit 25 Basepoint Business Centre, Aviation Park, West Christchurch, United Kingdom BH23 6NX
- www.momanx.com
- https://moman.co/youtube