

Installation & CARE

YG0801W053

Tools Required

16mm Socket
10mm Socket
Ratchet
Philips Screwdriver
Trim Tool

Part List

- | | | |
|---|-----|----------------------------|
| ① | ×2 | Running Board (L+R) |
| ② | ×2 | Front Bracket (14 inch) |
| ③ | ×2 | Rear Bracket (14-3/4 inch) |
| ④ | ×8 | M10 Bolt Plate |
| ⑤ | ×16 | M6 Square Head Bolt |
| ⑥ | ×4 | M6 Self-Tapping Screw |
| ⑦ | ×8 | M10 Flat Washer |
| ⑧ | ×16 | M6 Flat Washer |
| ⑨ | ×8 | M10 Spring Washer |
| ⑩ | ×8 | M10 Flange Nut |
| ⑪ | ×16 | M6 Flange Nut |
| ⑫ | ×10 | Expansion Buckle |
| ⑬ | ×4 | Bracket Spacer |
| ⑭ | ×1 | Foam Seal Strip |



Notes

Read this instruction carefully before starting installation.
Proper tools will improve the quality of installation and reduce the time required.
If missing parts or any damage found, please take a picture, and contact us.

Step 1:

1. Under the vehicle, pry up (6) rivets securing the splash guard.
2. Remove (1) M6 bolt in front wheel well and (3) rivets in rear wheel well.
3. Pull the splash guard outward and remove from vehicle.
4. Locate (2) mounting positions each side.




Step 2:


1. Insert M10 bolt plates into oval holes on the body panel, (4) bolt plates each side.



2. Attach the front bracket to the body panel, feed studs through mounting holes on bracket.




3. Secure the front bracket using (2) M10 flat washers, (2) M10 spring washers, (2) M10 flange nuts.





Note: passenger side is shown.

Step 3:

1. Attach the rear bracket to the body panel, feed studs through mounting holes on bracket.




2. Secure the rear bracket using (2) M10 flat washers, (2) M10 spring washers, (2) M10 flange nuts.





Step 4:

1. Insert (8) M6 square bolts into the mounting rails behind running board, (4) bolts per rail.
2. Place running board onto brackets.
3. Slide square bolts to align the slots on brackets.
4. Secure running board using (8) M6 flat washer, (8) M6 flange nuts.



Note: The running board may too close to interfere the passenger side door. Please refer following step to adjust.

1. Remove running board and brackets from vehicle.
2. Attach the bracket spacers to body panel before attach brackets.



3. Reinstall all hardware.

Step 5:

1. Push the running board inward to engage all claws and clips. Seal the gap using the foam seal strip.
2. Attach the rear splash guard to the rear end of the running board, using (2) rivets, (1) factory hex screw, (2) M6 self-tapping screws to secure.



3. Secure the front end of running board using (2) rivets.



4. Tighten all hardware, period check to ensure all mounting hardware remains secure and tight.



Installation & CARE