


# **User's Manual**




www.rbrohant.com

# **INSTALLATION INSTRUCTIONS**

# **Installation Manual**





**RB0949** 

#### IAPMO RESEARCH AND TESTING, INC.










### CERTIFICATE OF LISTING

Plumbing Fixture Fittings

File No. 8737









#### IAPMO RESEARCH AND TESTING, INC.















#### IAPMO RESEARCH AND TESTING, INC.













# **INSTALLATION STEPS**


This product has been inspected and debugged by the factory to the best condition. Please do not disassemble and assemble it yourself.




1. According to the basic size of the embedded box, use a special tool to open the main hole on the solid wall. The depth of the hole is as shown in the figure. It should be ensured that the distance between the surface of the finished wall and the bottom of the hole is between 2.16" and 2.56".




3. Connect the inlet and outlet pipes as shown in the picture.



Before installing the faucet, please be sure to remove sundries and sludge from the water pipe to prevent sundries from blocking the faucet.




2. First find the stainless steel fixing bracket, and screw it to the upper and lower extension positions of the embedded box; The slot size on the wall is 14.49"X4.72"




4. "Water tightness test:"

Keep the shower handle closed and turn on the hot and cold water inlet pipe switch. After 5 minutes, check whether there is leakage at the interface between the main body and the water inlet pipe. Block the rain shower outlet and the hand-held water outlet, keep the shower handle open, adjust the water divider, check whether there is leakage at the interface between the main body and the water outlet pipe.




# **INSTALLATION STEPS**


5. Make sure again that the pipeline connection is correct and that there is no leakage in the test water. Seal the embedded box and the pipeline with filler and take out the plastic protective cover.




7. As shown in the picture, install flange, diverter handle and cartridge handle.




8. After installation, test whether each function is used normally, and wipe the surface of the faucet with a soft cloth.




6. As shown in the picture, affix the tiles, and open two holes with a diameter of 1.97" in the middle tile, with a distance of 5.91" between the two holes.



9. Install shower arm and shower head (wrap the PTFE tape on the thread).



# **INSTALLATION DIMENSION**



The picture is for reference only, you can install it according to your own requirements.

## **CLEANING CARE**

In order to keep the appearance of faucet clean, bright and good performance, please take care of the faucet as follows;

- 1. Rinse with water only and dry with soff cotton cloth;
- 2.Use mild liquid and colorless glass cleaner to remove surface dirt and scale film, or use polish without abrasive effect;
- 3.Do not use abrasive deterfgent, polish, emery cloth, paper towel or scraper, etc.;
- 4.Do not use acid cleaner, or cleaner and soap with insoluble gran etc.;
- 5.In the process of use, mud my accumulate in the bubbler and make the water flow show, The bubbler can be unscrewed, rinsed with water, and then installed back in place.

Please feel free to contact us if you have any questions. We will help to solve the issue together with you. OUR EMAIL: services@rbrohant.com





Service Contact:

+1(801) 800-9309 services@rbrohant.com

Made in China