

J3M002




As this item contains many parts, please read the installation instruction carefully before installation . Please use tools properly and carefully. If you have any questions about the product and installation, please contact us.

service@vabches.com

Our professional after-sales team will serve you online all day.

Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

Helpful Hints


PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.
- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.




Board Identification

Not actual size




(A)

MIDDLE PANEL
Qty:1




(B)

LOWER LEFT SIDE PANEL
Qty:1




(C)

LOWER RIGHT SIDE PANEL
Qty:1




(D)

LOWER PARTITION
Qty:1




(E)

RAIL
Qty:1




(F)

REAR TRANSVERSE PANEL
Qty:1




(G)

CIRCULAR TUBE
Qty:1




(H)

FLAP
Qty:1




(I)

FIXED SHELF
Qty:1




(J)

FIXED SHELF
Qty:1



(K)

BOTTOM
Qty:1




(L)


RAIL
Qty:1

Board Identification


Not actual size




(M)
UPPER PARTITION
Qty:1




(N)
LOWER BACK PANEL
Qty:1




(O)
MIDDLE BACK PANEL
Qty:1




(P)
UPPER BACK PANEL
Qty:1




(Q)
RAIL
Qty:1




(R)
TOP
Qty:1




(S)
RAIL
Qty:1




(T)
TRACK
Qty:1




(U)
ADJUSTABLE SHELF
Qty:1



(V)
FIXED SHELF
Qty:1




(W)
UPPER LEFT SIDE PANEL
Qty:1



(X)
UPPER RIGHT SIDE PANEL
Qty:1

Board Identification


Not actual size




Y

DOOR PANEL
Qty:1


Part List




CAM LOCK
spare:3




CAM BOLT
spare:3




WOODEN DOWEL
spare:3




BOLT
spare:1




SCREW
spare:3




SCREW
spare:1




SCREW
spare:1




SCREW
spare:1




MAGNETIC CATCHER



METAL PLATE




DOOR PIVOT




RUBBER RING


Part List




BOLT
spare:1




HANDLE




SHELF SUPPORT
spare:1




PERFECT STICKERS
spare:3




HEX KEY



PULLEY




ANTI-TIPPING HARDWARE



SHELF SUPPORT


Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.








Board Identification





Not actual size






STEP1










STEP2

							
Ø4X35mm		M4X25mm		Ø18(Ø8)X10mm		4X65mm	
5	X3	4	X3	12	X3	17	X1










STEP3









Proper orientation of CAM LOCK

STEP4








Proper orientation of CAM LOCK

STEP5







STEP6








Proper orientation of CAM LOCK

STEP7






Proper orientation of CAM LOCK










STEP8









STEP9






STEP10










STEP11






STEP12





STEP13








STEP14






STEP15













STEP16







STEP17











STEP18




STEP19



STEP20




Stick the exposed holes of the cabinet body with hole stickers (16)



Stick the exposed holes of the cabinet body with hole stickers (16)

STEP21




We have included a set of tipping restraint hardware for this unit. You must install this hardware to prevent accidents or injuries that can result from the unit falling. When properly installed, this restraint can provide protection against the unexpected tipping of the unit due to small tremors, bumps or climbing. We strongly recommend mounting this hardware to a wall stud and your unit.


NOTE: The tipping restraint hardware included is for wooden stud wall construction. It must be attached to a wall stud. Depending upon your wall construction different anchor hardware may be required. Please contact your local hardware store for assistance. Young children can be seriously injured by tipping furniture. You must install the tipping restraint hardware with the unit to prevent the unit from tipping, causing any accidents or damage. The tipping restraints are intended only as a deterrent and are not a substitute for proper adult supervision. The tipping restraints are not earthquake restraints. If you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.




Install the tipping restraint hardware




1. make mark on the wall




2. drill two Ø6 holes on the wall



3. put two anchors in the holes



4. fix the device on the wall by the long screws



5. Push the cabinet close to the wall so that the two bases are close to each other, and then put on nylon tie to tighten it.

