A10s Pro

Receiving Card

Specifications

Change History

Document Version	Release Date	Description
V1.1.2	2022-02-28	• Added the dimensions diagram description. • Updated the certifications description. • Updated some feature descriptions.
V1.1.1	2021-08-10	• Updated the product introduction. • Updated the description of Dynamic Booster, Full-Grayscale Calibration and HDR functions.
V1.1.0	2021-07-30	• Updated the appearance diagram. • Updated the feature description.
V1.0.0	2021-06-03	First release

Introduction

The A10s Pro is a fully-featured high-end small receiving card developed by NovaStar. A single A10s Pro supports resolutions up to 512×512@60Hz. It supports the exclusive Dynamic Booster, Full-Grayscale Calibration and Image Booster technologies of NovaStar. The Dynamic Booster can significantly improve the display contrast. The Full-Grayscale Calibration can make the display brightness and chroma more uniform at different grayscale levels. The Image Booster can precisely calibrate the display color gamut and grayscale and improve the grayscale by 64 times.

The A10s Pro also supports the pixel level brightness and chroma calibration, quick adjustment of dark or bright lines, low latency, 3D, individual gamma adjustment for RGB, image rotation in 90° increments, image rotation at any angle, and HDR functions, greatly improving the brightness, grayscale and color performance from every aspect and offering users an ultimate visual experience with a uniform, smooth and lifelike image.

The A10s Pro uses high-density connectors for communication to limit the effects of dust and vibration, resulting in high stability. It supports up to 32 groups of parallel RGB data or 64 groups of serial data (expandable to 128 groups of serial data). Its reserved pins allow for custom functions of users. Thanks to its EMC Class B compliant hardware design, the A10s Pro has improved electromagnetic compatibility and is suitable for various on-site setups that have high requirements.

Certifications

RoHS, EMC Class B

If the product does not have the relevant certifications required by the countries or regions where it is to be sold, please contact NovaStar to confirm or address the problem. Otherwise, the customer shall be responsible for the legal risks caused or NovaStar has the right to claim compensation.

Features

Improvements to Display Effect

- Dynamic Booster
  Significantly improve the display contrast and image details for better visual experience and effectively control and lower the display power consumption.

- Full-Grayscale Calibration
  Each grayscale level of the input source has its own unique calibration coefficients, which can achieve uniform display brightness and chroma in high brightness, medium grayscale, and low grayscale at the same time.

- HDR function
  HDR10 and HLG are supported.

  Work with the sending card that supports the HDR function to correctly parse the HDR video source and faithfully reproduce the original brightness range and color space, allowing for a more lifelike image.

- Image Booster
  The Image Booster has the following 3 functions that improve the display effect (the actual effect depends on the driver IC) from different dimensions.

  - Color Management: Allow users to freely switch the color gamut of the screen between different gamuts in real time to enable more precise colors on the screen.

  - Precise Grayscale: Individually correct the 65,536 levels of grayscale (16bit) of the driver IC to fix the display problems at low grayscale conditions, such as brightness spikes, brightness dips, color cast and mottling. This function can also better assist other display technologies, such as 22bit+ and individual gamma adjustment for RGB, allowing for a smoother and uniform image.

  - 22bit+: Improve the LED display grayscale by 64 times to avoid grayscale loss due to low brightness and allow for more details in dark areas and a smoother image.

  NovaLCT V5.4.0 or later is required.

- Pixel level brightness and chroma calibration
  Work with NovaStar's high-precision calibration system to calibrate the brightness and chroma of

each pixel, effectively removing brightness differences and chroma differences, and enabling high brightness consistency and chroma consistency.

- Quick adjustment of dark or bright lines
  The dark or bright lines caused by splicing of modules or cabinets can be adjusted to improve the visual experience. The adjustment is easy and takes effect immediately.

- Low latency
  The latency of video source on the receiving card end can be reduced to 1 frame (only when using modules with driver IC with built-in RAM).

- 3D function
  Working with the sending card that supports 3D function, the receiving card supports 3D output.

- Individual gamma adjustment for RGB
  Working with NovaLCT (V5.2.0 or later) and the sending card that supports this function, the receiving card supports individual adjustment of red gamma, green gamma and blue gamma, which can effectively control image non-uniformity at low grayscale conditions and white balance offset, allowing for a more realistic image.

- Image rotation in 90° increments
  The display image can be set to rotate in multiples of 90° (0°/90°/180°/270°).

- Image rotation at any angle
  Working with SmartLCT and the MCTRL R5 LED display controller, the receiving card supports image rotation at any angle.

Improvements to Maintainability

- Automatic module calibration
  After a new module with flash memory is installed to replace the old one, the calibration coefficients stored in the memory can be automatically uploaded to the receiving card when it is powered on.

- Quick uploading of calibration coefficients
 Upload the calibration coefficients quickly to the receiving cards to improve efficiency.

- Module Flash management
  For modules with flash memory, the information stored in the memory can be managed. The calibration coefficients and module ID can be stored and read back.

- One click to apply calibration coefficients in module Flash
  For modules with flash memory, when the Ethernet cable is disconnected, users can hold down the self-test button on the cabinet to upload the calibration coefficients in the memory of the module to the receiving card.

- Mapping function
  The cabinets can display the sending card number, Ethernet port number and receiving card number, allowing users to easily obtain the locations and connection topology of receiving cards.

- Setting of a pre-stored image in receiving card
  The image displayed during startup, or displayed when the Ethernet cable is disconnected or there is no video signal can be customized.

- Temperature and voltage monitoring
  The receiving card temperature and voltage can be monitored without using peripherals.

- Bite error detection
  The Ethernet port communication quality of the receiving card can be monitored and the number of erroneous packets can be recorded to help troubleshoot network communication problems.

  NovaLCT V5.2.0 or later is required.

- Status detection of dual power supplies
  When two power supplies are used, their working status can be detected by the receiving card.

- Firmware program readback
  The receiving card firmware program can be read back and saved to the local computer.

  NovaLCT V5.2.0 or later is required.

- Configuration parameter readback
  The receiving card configuration parameters can be read back and saved to the local computer.

- LVDS transmission (dedicated firmware required)
  Low-voltage differential signaling (LVDS) transmission is used to reduce the number of data cables from the hub board to module,

increase the transmission distance, and improve the signal transmission quality and electromagnetic compatibility (EMC).

Improvements to Reliability

- Dual card backup and status monitoring
  In an application with requirements for high reliability, two receiving cards can be mounted onto a single hub board for backup. When the primary receiving card fails, the backup card can serve immediately to ensure uninterrupted operation of the display.

  The working status of the primary and backup receiving cards can be monitored in NovaLCT V5.2.0 or later.

- Loop backup
  The receiving card and sending card form a loop via the primary and backup line connections. When a fault occurs at a location of the lines, the screen can still display the image normally.

- Dual backup of configuration parameters
  The receiving card configuration parameters are stored in the application area and factory area of the receiving card at the same time. Users usually use the configuration parameters in the application area. If necessary, users can restore the configuration parameters in the factory area to the application area.

- Dual program backup
  Two copies of firmware program are stored in the application area of the receiving card at the factory to avoid the problem that the receiving card may get stuck abnormally during program update.

- Dual backup of calibration coefficients
  The calibration coefficients are stored in the application area and factory area of the receiving card at the same time. Users usually use the calibration coefficients in the application area. If necessary, users can restore the calibration coefficients in the factory area to the application area.

Appearance

Top

Bottom

Power Indicator   Running Indicator

High-Density Connectors

All product pictures shown in this document are for illustration purpose only. Actual product may vary.

Indicators

Indicator	Color	Status	Description
Running indicator	Green	Flashing once every 1s	The receiving card is functioning normally. Ethernet cable connection is normal, and video source input is available.
		Flashing once every 3s	Ethernet cable connection is abnormal.
		Flashing 3 times every 0.5s	Ethernet cable connection is normal, but no video source input is available.
		Flashing once every 0.2s	The receiving card failed to load the program in the application area and is now using the backup program.
		Flashing 8 times every 0.5s	A redundancy switchover occurred on the Ethernet port and the loop backup has taken effect.
Power indicator	Red	Always on	The power input is normal.

Dimensions

The board thickness is not greater than 2.0 mm, and the total thickness (board thickness + thickness of components on the top and bottom sides) is not greater than 8.5 mm. Ground connection (GND) is enabled for mounting holes.

Tolerance: ±0.3   Unit: mm

Note

The distance between outer surfaces of the A10s Pro and hub boards after their high-density connectors fit together is 5.0 mm. A 5-mm copper pillar is recommended.

To make molds or trepan mounting holes, please contact NovaStar for a higher-precision structural drawing.

Pins

32 Groups of Parallel Data

JH1 / JH2 connector pinout diagram

JH1					
	GND	1	2	GND	
	NC	3	4	NC	
	NC	5	6	NC	
	NC	7	8	NC	
	NC	9	10	NC	
	NC	11	12	NC	
	NC	13	14	NC	
	NC	15	16	NC	
/	RFU1	17	18	NC	
/	RFU2	19	20	NC	

		JH1			
	GND	21	22	NC	
	NC	23	24	NC	
	GND	25	26	GND	
/	G17	27	28	R17	/
/	R18	29	30	B17	/
/	B18	31	32	G18	/
/	G19	33	34	R19	/
/	R20	35	36	B19	/
/	B20	37	38	G20	/
	GND	39	40	GND	
/	G21	41	42	R21	/
/	R22	43	44	B21	/
/	B22	45	46	G22	/
/	G23	47	48	R23	/
/	R24	49	50	B23	/
/	B24	51	52	G24	/
	GND	53	54	GND	
/	G25	55	56	R25	/
/	R26	57	58	B25	/
/	B26	59	60	G26	/
/	G27	61	62	R27	/
/	R28	63	64	B27	/
/	B28	65	66	G28	/
	GND	67	68	GND	
/	G29	69	70	R29	/
/	R30	71	72	B29	/
/	B30	73	74	G30	/
/	G31	75	76	R31	/
/	R32	77	78	B31	/
/	B32	79	80	G32	/
	GND	81	82	GND	
/	RFU4	83	84	RFU3	/
/	RFU6	85	86	RFU5	/
/	RFU8	87	88	RFU7	/
/	RFU10	89	90	RFU9	/
/	RFU12	91	92	RFU11	/
/	RFU14	93	94	RFU13	/
	GND	95	96	GND	
/	RFU16	97	98	RFU15	/
/	RFU18	99	100	RFU17	/
	NC	101	102	NC	
	NC	103	104	NC	
	NC	105	106	NC	
	NC	107	108	NC	
	GND	109	110	GND	
	GND	111	112	GND	
	NC	113	114	NC	
	EXT_5V	115	116	EXT_5V	
	EXT_5V	117	118	EXT_5V	
	EXT_5V	119	120	EXT_5V	

		JH2			
Chassis ground	Eth_Sheild	1	2	Eth_Sheild	Chassis ground
Chassis ground	Eth_Sheild	3	4	Eth_Sheild	Chassis ground
	NC	5	6	NC	
	NC	7	8	NC	
Gigabit Ethernet port	Port1_T0+	9	10	Port2_T0+	Gigabit Ethernet port
	Port1_T0-	11	12	Port2_T0-	

	JH2				
	NC	13	14	NC	
	Port1_T1+	15	16	Port2_T1+	
	Port1_T1-	17	18	Port2_T1-	
	NC	19	20	NC	
	Port1_T2+	21	22	Port2_T2+	
	Port1_T2-	23	24	Port2_T2-	
	NC	25	26	NC	
	Port1_T3+	27	28	Port2_T3+	
	Port1_T3-	29	30	Port2_T3-	
	NC	31	32	NC	
Tri-color LED (Reserved)	STA_LEDB-	33	34	STA_LEDR-	Tri-color LED (Reserved)
Test button	Input_KEY_IN	35	36	STA_LEDG-	Running indicator (active low) Tri-color LED (Reserved)
	GND	37	38	GND	
Line decoding signal	A	39	40	DCLK1	Shift clock output 1
Line decoding signal	B	41	42	DCLK2	Shift clock output 2
Line decoding signal	C	43	44	LAT	Latch signal output
Line decoding signal	D	45	46	CTRL	Afterglow control signal
Line decoding signal	E	47	48	OE_R	Display enable signal
Display enable signal	OE_B	49	50	OE_G	Display enable signal
	GND	51	52	GND	
/	G1	53	54	R1	/
/	R2	55	56	B1	/
/	B2	57	58	G2	/
/	G3	59	60	R3	/
/	R4	61	62	B3	/
/	B4	63	64	G4	/
	GND	65	66	GND	
/	G5	67	68	R5	/
/	R6	69	70	B5	/
/	B6	71	72	G6	/
/	G7	73	74	R7	/
/	R8	75	76	B7	/
/	B8	77	78	G8	/
	GND	79	80	GND	
/	G9	81	82	R9	/
/	R10	83	84	B9	/
/	B10	85	86	G10	/
/	G11	87	88	R11	/
/	R12	89	90	B11	/
/	B12	91	92	G12	/
	GND	93	94	GND	
/	G13	95	96	R13	/
/	R14	97	98	B13	/
/	B14	99	100	G14	/
/	G15	101	102	R15	/
/	R16	103	104	B15	/
/	B16	105	106	G16	/
	GND	107	108	GND	
	NC	109	110	NC	
	NC	111	112	NC	
	NC	113	114	NC	
	NC	115	116	NC	
	GND	117	118	GND	

JH2				
	GND	119	120	GND	

64 Groups of Serial Data

JH1				
	GND	1	2	GND	
	NC	3	4	NC	
	NC	5	6	NC	
	NC	7	8	NC	
	NC	9	10	NC	
	NC	11	12	NC	
	NC	13	14	NC	
	NC	15	16	NC	
/	RFU1	17	18	NC	

JH1					
/	RFU2	19	20	NC	
	GND	21	22	NC	
	NC	23	24	NC	
	GND	25	26	GND	
/	Data50	27	28	Data49	/
/	Data52	29	30	Data51	/
/	Data54	31	32	Data53	/
/	Data56	33	34	Data55	/
/	Data58	35	36	Data57	/
/	Data60	37	38	Data59	/
	GND	39	40	GND	
/	Data62	41	42	Data61	/
/	Data64	43	44	Data63	/
	NC	45	46	NC	
	NC	47	48	NC	
	NC	49	50	NC	
	NC	51	52	NC	
	GND	53	54	GND	
	NC	55	56	NC	
	NC	57	58	NC	
	NC	59	60	NC	
	NC	61	62	NC	
	NC	63	64	NC	
	NC	65	66	NC	
	GND	67	68	GND	
	NC	69	70	NC	
	NC	71	72	NC	
	NC	73	74	NC	
	NC	75	76	NC	
	NC	77	78	NC	
	NC	79	80	NC	
	GND	81	82	GND	
/	RFU4	83	84	RFU3	/
/	RFU6	85	86	RFU5	/
/	RFU8	87	88	RFU7	/
/	RFU10	89	90	RFU9	/
/	RFU12	91	92	RFU11	/
/	RFU14	93	94	RFU13	/
	GND	95	96	GND	
/	RFU16	97	98	RFU15	/
/	RFU18	99	100	RFU17	/
	NC	101	102	NC	
	NC	103	104	NC	
	NC	105	106	NC	
	NC	107	108	NC	
	GND	109	110	GND	
	GND	111	112	GND	
	NC	113	114	NC	
	EXT_5V	115	116	EXT_5V	
	EXT_5V	117	118	EXT_5V	
	EXT_5V	119	120	EXT_5V	

JH2					

JH2					
Chassis ground	Eth_Sheild	1	2	Eth_Sheild	Chassis ground
Chassis ground	Eth_Sheild	3	4	Eth_Sheild	Chassis ground
	NC	5	6	NC	
	NC	7	8	NC	
Gigabit Ethernet port	Port1_T0+	9	10	Port2_T0+	Gigabit Ethernet port
	Port1_T0-	11	12	Port2_T0-	
	NC	13	14	NC	
	Port1_T1+	15	16	Port2_T1+	
	Port1_T1-	17	18	Port2_T1-	
	NC	19	20	NC	
	Port1_T2+	21	22	Port2_T2+	
	Port1_T2-	23	24	Port2_T2-	
	NC	25	26	NC	
	Port1_T3+	27	28	Port2_T3+	
	Port1_T3-	29	30	Port2_T3-	
	NC	31	32	NC	
Tri-color LED (Reserved)	STA_LEDB-	33	34	STA_LEDR-	Tri-color LED (Reserved)
Test button	Input_KEY_IN	35	36	STA_LEDG-	Running indicator (active low) Tri-color LED (Reserved)
	GND	37	38	GND	
Line decoding signal	A	39	40	DCLK1	Shift clock output 1
Line decoding signal	B	41	42	DCLK2	Shift clock output 2
Line decoding signal	C	43	44	LAT	Latch signal output
Line decoding signal	D	45	46	CTRL	Afterglow control signal
Line decoding signal	E	47	48	OE_R	Display enable signal
Display enable signal	OE_B	49	50	OE_G	Display enable signal
	GND	51	52	GND	
/	Data2	53	54	Data1	/
/	Data4	55	56	Data3	/
/	Data6	57	58	Data5	/
/	Data8	59	60	Data7	/
/	Data10	61	62	Data9	/
/	Data12	63	64	Data11	/
	GND	65	66	GND	
/	Data14	67	68	Data13	/
/	Data16	69	70	Data15	/
/	Data18	71	72	Data17	/
/	Data20	73	74	Data19	/
/	Data22	75	76	Data21	/
/	Data24	77	78	Data23	/
	GND	79	80	GND	
/	Data26	81	82	Data25	/
/	Data28	83	84	Data27	/
/	Data30	85	86	Data29	/
/	Data32	87	88	Data31	/
/	Data34	89	90	Data33	/
/	Data36	91	92	Data35	/
	GND	93	94	GND	
/	Data38	95	96	Data37	/
/	Data40	97	98	Data39	/
/	Data42	99	100	Data41	/
/	Data44	101	102	Data43	/
/	Data46	103	104	Data45	/
/	Data48	105	106	Data47	/

	JH2				
	GND	107	108	GND	
	NC	109	110	NC	
	NC	111	112	NC	
	NC	113	114	NC	
	NC	115	116	NC	
	GND	117	118	GND	
	GND	119	120	GND	

Note:

The recommended power input is 5.0 V.

OE_R, OE_G and OE_B are display enable signals. When RGB are not controlled separately, use OE_R. When the PWM chip is used, they are used as GCLK signals.

In the mode of 128 groups of serial data, Data65–Data128 are multiplexed into Data1–Data64.

Reference Design for Extended Functions

Pins for Extended Functions		
Pin	Recommended Module Flash Pin	Description
RFU1	Reserved	A reserved pin for connection to MCU
RFU2	Reserved	A reserved pin for connection to MCU
RFU3	HUB_CODE0	Flash control pin 1
RFU4	HUB_SPI_CLK	Clock signal of serial pin
RFU5	HUB_CODE1	Flash control pin 2
RFU6	HUB_SPI_CS	CS signal of serial pin
RFU7	HUB_CODE2	Flash control pin 3
RFU8	HUB_SPI_MOSI	Module Flash data storage input
RFU9	HUB_CODE3	Flash control pin 4
RFU10	HUB_SPI_MISO	Module Flash data storage output
RFU11	HUB_H164_CSD	74HC164 data signal
RFU12	/	/
RFU13	HUB_H164_CLK	74HC164 clock signal
RFU14	POWER_STA1	Dual power supply detection signal 1
RFU15	MS_DATA	Dual card backup connection signal
RFU16	POWER_STA2	Dual power supply detection signal 2
RFU17	MS_ID	Dual card backup identifier signal
RFU18	HUB_CODE4	Flash control pin 5

Specifications

Maximum Resolution	512×512@60Hz	
Electrical Parameters	Input voltage	DC 3.3 V to 5.5 V
	Rated current	0.5 A
	Rated power consumption	2.5 W
Operating Environment	Temperature	–20°C to +70°C
	Humidity	10% RH to 90% RH, non-condensing
Storage	Temperature	–25°C to +125°C

Environment	Humidity	0% RH to 95% RH, non-condensing
Physical Specifications	Dimensions	80.0 mm × 45.0 mm × 8.0 mm
	Net weight	22.8 g
Packing Information	Packing specifications	An antistatic bag and anti-collision foam are provided for each receiving card. Each packing box contains 40 receiving cards.
	Packing box dimensions	378.0 mm × 190.0 mm × 120.0 mm

The amount of current and power consumption may vary depending on various factors such as product settings, usage, and environment.

Trademark

is a trademark of Xi'an NovaStar Tech Co., Ltd.

Statement

Thank you for choosing NovaStar's product. This document is intended to help you understand and use the product. For accuracy and reliability, NovaStar may make improvements and/or changes to this document at any time and without notice. If you experience any problems in use or have any suggestions, please contact us via the contact information given in this document. We will do our best to solve any issues, as well as evaluate and implement any suggestions.