


Hall voltage sensor

Sub-plate installation, Crimping terminal output. Detect DC, AC and pulse current, High insulation between primary side and the vice side circuit.







zero gain


Product features

- •Low power consumption
- · Good linearity
- No insertion loss
- Fast response time
- Good anti-interference ability

Product application

- Railway
- Metallurgical
- ·Welding machine
- Robot
- Motor
- •Inverter power supply
- Variable frequency governor
- •Uninterrupted power supply and communication power supply

High side after wiring Terminal proposal seal processing





$Electrical\ parameters:\ (\ The\ following\ parameters\ are\ typical\ values\ and\ actual\ values\ will\ be\ subject\ to\ product\ testing\)$

Remarks:

Ιp	Rated input	±50V	±100V	±200V	±300V	$\pm 400 \text{V}$	±500V	Standard input
Ipm	Input measurement range	±75V	±150V	±300V	±450V	$\pm600\mathrm{V}$	±750V	Default is 1.5 times of rated input
Vout	Rated output	±5V						Standard output
X	Accuracy	1%						I = I p
εL	Linearity	0.2%						$I=0^{\sim} \pm Ip$
Vс	Supply voltage	\pm 12V/ \pm 15V						One or the other Supply voltage range±5%
Ιc	Current consumption	$\leq \pm 15$ mA+Is						Reference will be subject to the measured
R1	Load impedance	≥10K Ω						Collection port impedance while lower voltage affect accuracy
Voe	Zero offset voltage	\leq \pm 30 m V						TA=25°C
Tr	Response time	40~200 μ s						Reference will be subject to the measured
N.w	Weight	185g						Reference will be subject to the measured
Ta	Operation temperature	-10 ~ +70 °C						
Ts	Storage temperature	-25 ∼ $+70$ °C						
Bw	Band width	-						Factory test according to DC
Vd	Delectric strength	3.5KV 50Hz 1min						

Instruction for use:

- 1. Correct wiring as indicated
- 2. Full scale measurement, response time and following the speed for the best
- 3. Faulty wiring can lead to product damage and output uncertainty

Safe operation:


- *Please read this specification carefully before use.
- *When you need to move the product, please be sure to disconnect the power and all the connected cables.
- *If found shell, devices attached to the fixed parts, wire, or have any damaged, please immediately deal with hidden dangers.
- *If there is any doubt about the safe operation of the equipment, the equipment and the corresponding accessories should be closed immediately, and the fastest time for troubleshooting.

Proclamations:


As our products are constantly being improved and updated, we reserve the right to modify the content of this specification at any time without prior notice.



Dimensions (in $mm\pm0.5$):




Side view



Top view

Wiring diagram:



Terminal definition:

1: +V

2: Vout

3: 0V

4: -V

5: -HT 6: Air terminal

8: +HT 7: Air terminal

※ Detection :

①Choose the auxiliary power supply with small ripple ($\leq 10 \text{mV}$)

②Switch on auxiliary power

3 The auxiliary power is connected to the sensor

4 The sensor detects the primary current