

# Hall voltage sensor

Din-rail indtallation, Crimping terminal output. Detect DC, AC and pulse current, High insulation between primary side and the vice side circuit.







Front view Bottom view


### Product features

- •Low power consumption
- Good linearity
- No insertion loss
- Fast response time
- Good anti-interference ability

# Product application

- Railway
- Metallurgical
- · Welding machine
- Robot
- Motor
- •Inverter power supply
- Variable frequency governor
- Uninterrupted power supply and communication power supply

High side after wiring
Terminal proposal seal processing





# Electrical parameters: ( The following parameters are typical values and actual values will be subject to product testing )

## Remarks:

$I_{_{\mathrm{PN}}}$	Rated input	±50V	±100V	±200V	±300V	±400V	±500V	Standard input
Ipm	Input measurement range	±70V	±150V	±300V	$\pm 450 \text{V}$	$\pm600\mathrm{V}$	±750V	Default is 1.5 times of rated input
Vout	Rated output	±5V						Standard output
X	Accuracy	1 %						$I = I_{PN}$
εL	Linearity	0.2%						$I=0^{\sim} \pm I_{PN}$
Vс	Supply voltage	$\pm$ 12V/ $\pm$ 15V						One or the other Supply voltage range±5%
Ιc	Current consumption	$\leq \pm 15 \text{mA+Is}$						Reference will be subject to the measured
R1	Load impedance	≥10KΩ						Collection port impedance while lower voltage affect accuracy
Voe	Zero offset voltage	$\leq$ $\pm$ 30 mV						TA=25°C
Tr	Response time	40~200 μ s						Reference will be subject to the measured
N.w	Weight	264g						Reference will be subject to the measured
Ta	Operation temperature	$-10$ $\sim$ $+70$ $^{\circ}$ C						
Ts	Storage temperature	-25 ∼ + $70$ °C						
Bw	Band width	-						Factory test according to DC
Vd	Delectric strength	3.5KV 50Hz 1min						

#### Instruction for use:

- 1. Correct wiring as indicated
- 2. Full scale measurement, response time and following the speed for the best
- 3. Faulty wiring can lead to product damage and output uncertainty

#### Safe operation:


- \*Please read this specification carefully before use.
- \*When you need to move the product, please be sure to disconnect the power and all the connected cables.
- \*If found shell, devices attached to the fixed parts, wire, or have any damaged, please immediately deal with hidden dangers.
- \*If there is any doubt about the safe operation of the equipment, the equipment and the corresponding accessories should be closed immediately, and the fastest time for troubleshooting.

#### Proclamations:

As our products are constantly being improved and updated, we reserve the right to modify the content of this specification at any time without prior notice.




### Dimensions (in $mm\pm0.5$ ):



Front view

Top View

## Wiring diagram:



# Terminal definition:

1: -HT

2: +HT

3: +V

4: -V

5: Vout

8: 0V

## **X** Detection:

- ①Choose the auxiliary power supply with small ripple ( $\leq 10 mV$ )
- ②Switch on auxiliary power
- 3 The auxiliary power is connected to the sensor
- 4)The sensor detects the primary current