

AC Voltage Tansmitter

Sub-plate mount, terminal output. Detect AC current. High insulation between primary and secondary circuits.








Installation diagram

Product features High side wiring terminal proposal seal after processing

- •Light weight
- •Low power consumption
- Good linearity
- •No insertion loss
- Fast response time
- •Good anti-interference ability

Product application

- Railway
- Metallurgical
- Welding machine
- Robot
- Motor
- •Inverter power supply
- Variable frequency governor
- •Uninterrupted power supply and communication power supply





 $Electrical\ parameters:\ (\ The\ following\ parameters\ are\ typical\ values\ and\ actual\ values\ will\ be\ subject\ to\ product\ testing\)$

Remarks

Rated input	1000V	2000V	3000V	4000V	Standard input
Input measurement range	1200V	2400V	3600V	4800V	Default is 1.2 times the input rating
Rated output	0-20mA/4-20mA/0-5V/1-5V/0-10V				Output one of five 0-10V output +24V power supply
Accuracy	1%				
Linearity	0.5%				
Supply voltage (\pm 5%)	+12V / +24V				One or the other Supply voltage range ±5%
Current consumption	≤35mA			Reference will be subject to the measured	
Load impedance	Current t 250Ω(Ty	Current type output: Voltage type output: $250\Omega(Typification)$ $\geq 10K\Omega$			
Zero offset voltage		pe output:	Voltage ty ±15mV	ype output:	TA=25°C
Response time	≤350mS				Reference will be subject to the measured
weight	2.5Kg				Reference will be subject to the measured
Operating temperature	-10 ∼ $+70$ °C				
Storage temperature	-25~+70°C				
Band width	25Hz~1KHz				
Delectric strength	10KV 50Hz 1min				

Instruction for use:

- 1. Correct wiring as indicated
- 2. Full scale measurement, response time and following the speed for the best
- 3. Faulty wiring can lead to product damage and output uncertainty

Safe operation:


- *Please read this specification carefully before use.
- *When you need to move the product, please be sure to disconnect the power and all the connected cables.
- *If found shell, devices attached to the fixed parts, wire, or have any damaged, please immediately deal with hidden dangers.
- *If there is any doubt about the safe operation of the equipment, the equipment and the corresponding accessories should be closed immediately, and the fastest time for troubleshooting.


Proclamations:

As our products are constantly being improved and updated, we reserve the right to modify the content of this specification at any time without prior notice.




Dimensions(in mm±0.5):





Wiring diagram:



Terminal definition:

- 1: +V
- 2: GND
- 3: out
- 4: GND
- -HT (Measured voltage)
- +HT (Measured voltage)
- X①The auxiliary power supply with ripple small (≤20mV) is selected
 - 2 Switch on auxiliary power
- 3 Auxiliary power is connected to the transmitter
- 4 Transmitter detects the primary current
- ⑤Both GND internals are not isolated