

## Hall split core current transducer

 $suspension\ indtallation\ ,\ terminal\ output. Detect\ DC\ current.\ High\ insulation\ between\ primary\ and\ secondary\ circuit$ 




# Installation diagram

## Product features

- ·Light weight
- •Low power consumption
- Good linearity
- No insertion loss
- Fast response time
- Good anti-interference ability

## Product application

- Railway
- Metallurgical
- Welding machine
- Robot
- Motor
- •Inverter power supply
- · Variable frequency governor
- •Uninterrupted power supply and communication power supply





Electrical parameters: ( The following parameters are typical values and actual values will be subject to product testing )						Remarks	
Rated input	600A 70	00A 800A	1000A	1200A	1500A	2000A	Standard input
Input measurement range	720A 84	40A 960A	1200A	1440A	1800A	2400A	Default is 1.2 times the input rating
Rated output	0-20mA/4-20mA/0-5V/1-5V/0-10V						Output one of five 0-10V output +24V power supply
Accuracy	1%						
Linearity	0.5%						
Supply voltage ( $\pm$ 5%)	+12V / +24V					Supply voltage range ±5%	
Current consumption		$\leq 48 \mathrm{mA} + \mathrm{Io}$					Reference will be subject to the measured
Load impedance	Currer 250Ω(	Current type output: Voltage type output: $250\Omega(Typification)$ $\geq 10K\Omega$					
Zero offset voltage	Curren ±0.08n	Current type output: ±0.08mA			e type ou	atput:	TA=25℃
Response time		≤350 m S					Reference will be subject to the measured
weight	761g					Reference will be subject to the measured	
Operating temperature		-10∼+70°C					
Storage temperature		-25∼+70°C					
Band width	$DC\!\sim\!400Hz$						

6KV 50Hz 1min

#### Instruction for use:

Delectric strength

- 1. Connect the wires correctly according to the marked connection mode
- 2. The direction indicated by an arrow for the positive current direction
- 3. With hole measurement, response time and following the speed for the best
- 4. Faulty wiring can lead to product damage and output uncertainty

### Safe operation:


- \*Please read this specification carefully before use.
- \*When you need to move the product, please be sure to disconnect the power and all the connected cables.
- \*If found shell, devices attached to the fixed parts, wire, or have any damaged, please immediately deal with hidden dangers.
- \*If there is any doubt about the safe operation of the equipment, the equipment and the corresponding accessories should be closed immediately, and the fastest time for troubleshooting.

#### Proclamations:


As our products are constantly being improved and updated, we reserve the right to modify the content of this specification at any time without prior notice.



### Dimensions(in $mm\pm0.5$ ):



## Wiring diagram:



## Connector Illustration





Crimping terminal fast plug2EDG-5.08-4p spacing 5.08mm

# Terminal definition:

1: +V

2: GND

3: out

4: GND

- \*\*①The auxiliary power supply with ripple small (≤20mV) is selected
- ②Switch on auxiliary power
- 3 Auxiliary power is connected to the transmitter
- **4** Transmitter detects the primary current
- ⑤Both GND internals are not isolated